


# *PNI Corporation*

*TCM3/5/5L*

Tilt Compensated 3-axis Compass Module



© Copyright  
PNI Corporation 2005

All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under copyright laws.

Revised November 2006  
For most recent version visit our website at  
[www.pnicorp.com](http://www.pnicorp.com)  
Printed in USA

PNI Corporation  
133 Aviation Blvd, Suite 101  
Santa Rosa, CA 95403, USA  
Tel: (707) 566-2260  
Fax: (707) 566-2261

**Warranty and Limitation of Liability.** PNI Corporation ("PNI") manufactures its TCM products ("Products") from parts and components that are new or equivalent to new in performance. PNI warrants that each Product to be delivered hereunder, if properly used, will, for one year following the date of shipment unless a different warranty time period for such Product is specified: (i) in PNI's Price List in effect at time of order acceptance; or (ii) on PNI's web site ([www.pnicorp.com](http://www.pnicorp.com)) at time of order acceptance, be free from defects in material and workmanship and will operate in accordance with PNI's published specifications and documentation for the Product in effect at time of order. PNI will make no changes to the specifications or manufacturing processes that affect form, fit, or function of the Product without written notice to the OEM, however, PNI may at any time, without such notice, make minor changes to specifications or manufacturing processes that do not affect the form, fit, or function of the Product. This warranty will be void if the Products' serial number, or other identification marks have been defaced, damaged, or removed. This warranty does not cover wear and tear due to normal use, or damage to the Product as the result of improper usage, neglect of care, alteration, accident, or unauthorized repair.

THE ABOVE WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, WHETHER EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE. PNI

NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO ASSUME FOR IT ANY OTHER LIABILITY.

If any Product furnished hereunder fails to conform to the above warranty, OEM's sole and exclusive remedy and PNI's sole and exclusive liability will be, at PNI's option, to repair, replace, or credit OEM's account with an amount equal to the price paid for any such Product which fails during the applicable warranty period provided that (i) OEM promptly notifies PNI in writing that such Product is defective and furnishes an explanation of the deficiency; (ii) such Product is returned to PNI's service facility at OEM's risk and expense; and (iii) PNI is satisfied that claimed deficiencies exist and were not caused by accident, misuse, neglect, alteration, repair, improper installation, or improper testing. If a Product is defective, transportation charges for the return of the Product to OEM within the United States and Canada will be paid by PNI. For all other locations, the warranty excludes all costs of shipping, customs clearance, and other related charges. PNI will have a reasonable time to make repairs or to replace the Product or to credit OEM's account. PNI warrants any such repaired or replacement Product to be free from defects in material and workmanship on the same terms as the Product originally purchased.

Except for the breach of warranty remedies set forth herein, or for personal injury, PNI shall have no liability for any indirect or speculative damages (including, but not limited to, consequential, incidental, punitive and special damages) relating to the use of or inability to use this Product, whether arising out of contract, negligence, tort, or under any warranty theory, or for infringement of any other party's intellectual property rights, irrespective of whether PNI had advance notice of the possibility of any such damages, including, but not limited to, loss of use, revenue or profit. In no event shall PNI's total liability for all claims regarding a Product exceed the price paid for the Product. PNI neither assumes nor authorizes any person to assume for it any other liabilities.

Some states and provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights that vary by state or province.

# About the TCM3/5/5L

Thank you for purchasing the TCM3/5/5L. You have chosen a product that represents the largest step forward in compass technology for many years. The TCM3/5/5L is a state-of-the-art, low power, high performance electronic tilt compensated compass sensor module.

The TCM3/5/5L uses advanced algorithms, with hard iron and soft iron corrections, to provide highly accurate heading information, in **any orientation** (TCM5 & TCM5L only), at latitudes up to 85°. The output information of the unit will indicate accurate attitude position of the module and can be used in systems requiring full 360° rotation (TCM5 & TCM5L only). This has been accomplished by integrating 3-axis magnetic field sensing, 3-axis tilt sensing, and compass heading into a single module, which is one of the smallest in the market. With its small size, the TCM3/5/5L is capable of fitting into today's size sensitive systems. These advantages make PNI Corporation's TCM3/5/5L the choice for applications that require the highest accuracy and performance anywhere in the world.

The TCM3/5/5L combines PNI Corporation's patented Magneto-Inductive (MI) sensors and measurement circuit technology with a 3-axis MEMS accelerometer for unparalleled cost effectiveness and performance. The magnetic sensors and accelerometers are calibrated to operate from -40 to 85°C; hence the measurement is very stable over temperature and inherently free from offset drift.

The TCM3/5/5L's advantages make it suitable for many applications, including:

- High-performance solid state navigation equipment
- High-performance attitude measurement
- IMU system integration
- 3-axis magnetic field sensing
- Robotics systems
- Laser range finders
- Drilling applications

With its many potential applications, the TCM3/5/5L provides a command set designed with flexibility and adaptability in mind. Many parameters are user-programmable, including reporting units, a wide range of sampling configurations, output damping, and more. We hope the TCM3/5/5L will help you to achieve the greatest performance from your target system. Thank you for selecting the TCM3/5/5L.

# Installation

This section describes how to configure, program, and control the TCM3/5/5L in your host system. To install the TCM3/5/5L into your system, follow these steps:

- **Make electrical connections to the TCM3/5/5L**
- **Evaluate the TCM3/5/5L using the included TCM Studio Program**
- **Choose a mounting location**
- **Mechanically mount the TCM3/5/5L**
- **Perform user calibration**

## Electrical Connections – TCM3/5

Included with the TCM3/5 Interface Kit is a cable to allow for the unit to be connected to your host system. On one end of the cable is the connector needed to mate with the TCM3/5. The cable's wires are color coded as indicated below.


PNI also has a 6-foot cable with a DB9 connector attached. Contact PNI Corporation for purchasing information.

<b>PIN</b>	<b>Wire Color</b>	<b>Description</b>
1	Black	Power Ground
2	Gray	NC
3	Green	RS232 Ground
4	Orange	NC
5	Violet	NC
6	Brown	NC
7	Yellow	TxD (Output of TCM)
8	Blue	RxD (Input of TCM)
9	Red	5 VDC

**TCM3/5 Pin Descriptions**

## Electrical Connections – TCM5L

The connector on the TCM5L is listed in the table below. The mate for the connector is from Preci-Dip, part number 851-93-004-100001101.



PIN	Description
1	Power Ground
2	5 VDC Supply
3	TxD (RS232)
4	RxD (RS232)

**TCM5L Pin Descriptions**

## RS-232 Serial Communication Interface

**Parameters** 8 data bits, 1 start bit, 1 stop bit, no parity

**Baud Rate** 300 to 230400

## *TCM Studio – Evaluation Program*

The TCM3/5/5L evaluation software communicates with the TCM3/5/5L through the COM port of your PC. It puts an easy-to-use interface onto the Binary command language used by the TCM3/5/5L, so that instead of issuing command codes manually, you can use buttons, check boxes, and dialog boxes. It reads the Binary responses of the TCM3/5/5L output strings and formats its sensor data into labeled and easy-to-read data fields. The program also includes the ability to log and save the outputs of the TCM3/5/5L to a file. All of this is so that you may begin to learn the capabilities of the TCM3/5/5L while using the TCM Studio program's more friendly interface. *Check the PNI website for the latest updates at [www.pnicorp.com](http://www.pnicorp.com).*

To install the TCM Studio program onto a **Windows** system:

1. Drag the "TCM Studio.exe" to the working directory of your computer.
2. Move the Quesa plug-in (Quesa.dll) into either the Windows System or System32 folder. Quesa is the OpenGL rendering engine and the 3D Model of the TCMStudio will not run without it.
  - For Windows 2000/NT copy to: /WinNT/System32 folder
  - For Windows XP copy to: /Windows/System32 folder

To install the TCM Studio program onto a **Mac OSX** system:

1. Drag the "TCM Studio" to the working directory of your computer.
2. Move the Quesa plug-in (Quesa) to: /Library/CFMSupport

### **[Connection Tab]**

#### **Initial Connection:**

1. Select 38400 as the baud rate.
2. Select the serial port the unit is plugged into.
3. Click on the <**Connect**> button.
4. Once a connection is made the "Connected" light will turn green and the Module, Firmware Version and Serial Number will be displayed.

#### **Change Baud Rate:**

1. Select new baud rate for the module.
2. Click on the <**Power Down**> button.
3. Select same baud rate for the computer.
4. Click on the <**Power Up**> button.

#### **Change Modules:**

Once connection has been made, the TCM Studio will remember the last settings. Any time a module is switched out, clicking on the <**Connect**> button once the new module is attached will reestablish a connection as long as the module baud rate is the same as the previous unit.

## **[Configuration Tab]**

**Note:** No settings will be changed in the unit until the <SAVE> button has been selected.

### **Mounting Options:**

**Note:** If the selection is grayed out or not listed the unit connected does not support this feature. Refer to “Mechanically Mounting – mounting option” section for additional information on mounting options.

**Standard:** When selected the unit is to be mounted with the main board in a horizontal position (the Z axis magnetic sensor is vertical).

**Standard 90 Degrees:** When selected the unit is to be mounted with the main board in a horizontal position but rotated so the arrow is pointed 90 degrees clockwise from the front of the host system.

**Standard 180 Degrees:** When selected the unit is to be mounted with the main board in a horizontal position but rotated so the arrow is pointed 180 degrees from the front of the host system.

**Standard 270 Degrees:** When selected the unit is to be mounted with the main board in a horizontal position but rotated so the arrow is pointed 270 degrees clockwise from the front of the host system.

**X Sensor Up:** When selected the unit is to be mounted with the main board in a vertical position (the X axis magnetic sensor is vertical).

**X Sensor Up Plus 90 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the X axis magnetic sensor is vertical) and rotated 90 degrees clockwise from the front of the host system.

**X Sensor Up Plus 180 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the X axis magnetic sensor is vertical) and rotated 180 degrees from the front of the host system.

**X Sensor Up Plus 270 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the X axis magnetic sensor is vertical) and rotated 270 degrees clockwise from the front of the host system.

**Y Sensor Up:** When selected the unit is to be mounted with the main board in a vertical position (the Y axis magnetic sensor is vertical).

**Y Sensor Up Plus 90 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the Y axis magnetic sensor is vertical) and rotated 90 degrees clockwise from the front of the host system.

**Y Sensor Up Plus 180 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the Y axis magnetic sensor is vertical) and rotated 180 degrees from the front of the host system.

**Y Sensor Up Plus 270 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the Y axis magnetic sensor is vertical) and rotated 270 degrees clockwise from the front of the host system.

**Z Sensor Down:** When selected the unit is to be mounted with the main board in a vertical position (the Z axis magnetic sensor is vertical).

**Z Sensor Down Plus 90 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the Z axis magnetic sensor is vertical) and rotated 90 degrees clockwise from the front of the host system.

**Z Sensor Down Plus 180 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the Z axis magnetic sensor is vertical) and rotated 180 degrees from the front of the host system.

**Z Sensor Up Plus 270 Degrees:** When selected the unit is to be mounted with the main board in a vertical position (the Z axis magnetic sensor is vertical) and rotated 270 degrees clockwise from the front of the host system.

### **North Reference:**

**Magnetic:** When the “Magnetic” radio button is selected, heading will be relative to Magnetic North.

**True:** When the “True” radio button is selected, heading will be relative to True North. To use North Heading in “True” mode, the declination needs to be set in the “Declination” window. Refer to “Using the TCM Declination Value” section for more information.

### **Endianess:**

Use to select either Big Endian or Little Endian; default is Big Endian.

### **Filter Settings:**

**Taps:** Use to select either a 0 (no filter), 4, 8, 16, or 32 samples and apply the values to a FIR filter prior to calculating the heading. These filters allow for a much more stable reading, but can make the acquisition of the data by the program slower. The default setting is 32.

### **Acquisition Parameters:**

#### **Mode:**

- When “Poll” is selected the TCM Studio program requests the data from the unit, and once it has been sent, the program will request the data again at the interval set in the “Poll Time” box. If the time is set to 0 then the TCM Studio will request the data as soon as the previous request has been fulfilled.
- When “Push” is selected the unit will be in **Interval Mode**, which is internal to the unit. Once the unit has been set to **Interval Mode** and the interval time has been set in the “Interval Time” setting box, the unit will send out the preset data at the desired interval without prompting. If the interval is set to 0 then the unit will send the data as soon as the previous data stream has been sent.

**Acquire Time:** The “Acquire Time” setting box sets the time between samples taken by the unit. This is an internal setting that is NOT tied to the time with which the unit transmits the data out to the program or host.

**Flush Filters:** The filtering is set to only update the filter with the last sample taken, for example once the initial 32 samples are taken any new sample is added to the end with the



first sample being dropped. In the case where the “Acquire Time” is set to a value it would be prudent to set the unit to flush the filter prior to calculating the heading. This flushing will require the unit to take 32 new samples to use for the calculation.

**Note:** If the “Flush Filters” checkbox is checked, it will take longer for the unit to output updated data.

### **User Cal Settings:**

**Stability Checking:** By default the unit will wait for the readings to be stable for 3 consecutive readings when in calibration mode prior to saving the sample for use in the calibration. This is why the unit must be held steady between points during the User Calibration. This stability helps to ensure a proper heading and allow for higher accuracy, but it also takes more time. If the user *de-selects* the check box, then the unit will NOT wait for a stable reading and instead take a reading once the minimum change between points threshold has been met.

**Automatic Sampling:** When selected the unit will take a point once the minimum change requirement and the stability check, if selected, has been satisfied. If the user wants to have more control over when the point will be taken then Auto Sampling should be deselected. Once deselected, the <Take Sample> button on the **Calibration** tab will be active. Selecting the <Take Sample> button will indicate to the unit to take a sample once the minimum requirements are met.

**Calibration Points:** The user can select the number of points to take during a calibration. The minimum number of points needed for a successful calibration is 12. The unit will need to be rotated through at least 180 degrees in the horizontal plane with a minimum of at least 1 positive and 1 negative Pitch and at least 1 positive and 1 negative Roll as part of the 12 points.

**Enable 3D Model:** Some computer systems may not have the graphics capability to render the 3D Model, for this reason it may be necessary to turn off this feature.

### **Default:**

This button will set the TCM Studio program back to the factory default settings.

### **Revert:**

This button will have the TCM Studio program read the settings from the unit and display them on the screen.

## **[Calibration Tab]**

**Note:** The default settings of the unit are recommended for the highest accuracy and quality of calibration.

### **Samples:**

1. Click on the **<Start>** button to begin.
2. To take a sample point, the unit will need to be held steady for a short time. Once the window indicates the next number, the unit can be moved some distance and held steady for the next sample. A minimum change of 30 degrees in heading or tilt is required for a sample to be taken. The larger the distance between points the better. The amount of Pitch and Roll during the calibration will determine the amount of Pitch and Roll the unit will be able to compensate for during use. Once the pre-set number of samples has been taken the calibration is complete.

**Note:** The minimum points the unit can use for a successful calibration is 12. The unit will need to be rotated through at least 180 degrees in the horizontal plane with minimum of at least 1 positive and 1 negative Pitch and Roll as part of the 12 points.

### **Results:**

1. Once the calibration is complete the “Coverage” window will indicate the quality of the calibration. The X, Y, and Z values show a percentage of each vector that has been covered during the calibration. The only way to get a Z value greater than 50% would be to take some points with the unit upside-down. The value shown in  $\mu T$  refers to the standard deviation of the measured samples when compared to the calculated values. The smaller the number the better. If a better score is needed, click on the **<Start>** button to begin a new calibration.

**Note:** The value in  $\mu T$  only refers to the quality of the calibration and NOT the accuracy of the heading. It is possible to have a “good” calibration but poor accuracy if the field the unit is exposed to during use is not the same as that which was present during the calibration.

2. If the calibration is sufficient then click on the **<Save>** button to save the calibration. If this button is not selected then the unit will need to be recalibrated after a power cycle.

### **Current Configuration:**

**Stability Checking:** Indicates if the Stability Checking option has been selected.

**Automatic Sampling:** Indicates if the Automatic Sampling option has been selected.

**Number of samples is:** Indicates the number of samples to be taken for the current calibration.

### **Options:**

**Audible Feedback:** If selected the TCM Studio will give an audible signal once a calibration point has been taken.

### **Clear:**

This button will clear the user calibration in the unit. Once selected, the unit will revert back to its factory calibration.

### ***[Test Tab]***

#### **Current Reading:**

Once the <GO> button is selected the unit will begin outputting Heading, Pitch and Roll information. Selecting the <Stop> button or changing tabs will halt the output of the unit.

#### **Contrast:**

Reverses the background color of the current reading window.

#### **Acquisition Settings:**

This window indicates the pertinent setting information.

#### **3D Model:**

The helicopter will follow the movement of the attached module and give a clear representation of the module's orientation.

### ***[Data Logger Tab]***

1. Select the data to log in the "Data" window.
2. Use **Shift-Ctrl-Click** and **Ctrl-Click** to select multiple items.
3. Click on the <GO> button to start logging; click the <STOP> button to stop logging.
4. Click on the <Export> button to save the data to a file.
5. Click on the <Clear> button to clear the data from the window.

Note: The data logger use ticks for time reference. A tick is 1/60 second.

### ***[System Log Tab]***

#### **Export:**

Select the <Export> button to save the system log to a file.

### ***[Graph]***

The graph provides a 2-axis (X,Y) plot of the measured field strength. The graph can be used to visually see hard and soft iron effects within the environment measured by the TCM module as well as corrected output after a user calibration has been performed.

## *Where to install the TCM3/5/5L*

The TCM3/5/5L's magnetometers' wide dynamic range and its sophisticated calibration algorithms allow it to operate in many environments. For optimal performance however, you should mount the TCM3/5/5L with the following considerations in mind:

### ***The TCM3/5/5L's magnetometers should not saturate***

The TCM3/5/5L can be user calibrated to correct for large static magnetic fields created by the host system. However, each axis of the TCM3/5/5L's magnetometers has a maximum dynamic range of  $\pm 80 \mu\text{T}$ ; if the total field exceeds this value for any axis, the TCM3/5/5L will not give accurate heading information. When mounting the TCM3/5/5L, consider the effect of any sources of magnetic fields in the local environment that when added to the earth's field may saturate the TCM3/5/5L's sensors. For example, large masses of ferrous metals such as transformers and vehicle chassis, large electric currents, permanent magnets such as electric motors, and so on.

### ***Locate the TCM3/5/5L away from local sources of changing magnetic fields***

It is not possible to calibrate for changing magnetic anomalies. Thus, for greatest accuracy, keep the TCM3/5/5L away from sources of local magnetic anomalies that will change with time; for instance, electric equipment that will be turned on and off or nearby ferrous bodies that will be changing positions. Make sure the TCM3/5/5L is not mounted close to cargo or payload areas that may be loaded with large sources of local magnetic fields.


### ***The TCM3/5/5L should be mounted in a physically stable location***

Choose a location that is isolated from excessive shock, oscillation, and vibration.


## Mechanically mounting the TCM3/5

Refer to the TCM3/5/5L Dimensional Specification later in this manual for the TCM3/5/5L board dimensions and the orientation of the reference frame.

The TCM3/5/5L is factory calibrated with respect to the mounting holes, as shown below, thus it must be aligned within the host system with respect to these mounting holes, not the board edges.



## TCM3/5




## TCM5L

## Mounting Options


The TCM3/5/5L is able to be mounted in various positions to allow for greater flexibility. All reference points are based on the white silk-screened arrow on the top side of the board.

**Note:** The board depicted below is for illustration purposes only and does not show the actual TCM3/5/5L board.

### TCM3/5 Mounting Options



## TCM5L Mounting Options



## Using the TCM3/5/5L

### *User Calibration*

All compasses can perform well in a controlled environment, where the ambient magnetic field consists solely of the earth's field. In most practical applications, however, an electronic compass module will be mounted in a host system such as a vehicle that can contain large sources of local magnetic fields: ferrous metal chassis, transformer cores, electrical currents, and permanent magnets in electric motors.

By performing the user calibration procedure, you allow the TCM3/5/5L to identify the major sources of these local magnetic anomalies and subsequently cancel out their effects when measuring the earth's magnetic field for computing compass headings. When you perform the user calibration procedure, the TCM3/5/5L takes a series of magnetic field measurements. It analyzes these total field measurements in order to identify the components that are created by the earth's field, which is the desired signal, from those components that are generated by the local environment, which we wish to subtract out.

The end goal of the procedure for the TCM3/5/5L is to have an accurate measurement of the static three-dimensional magnetic field vector generated by its host system at its mounting location. This vector is subsequently subtracted out of run-time field measurement to yield the resultant earth's field vector.

One major benefit from the TCM3/5/5L's triaxial magnetometer/triaxial accelerometer system configuration is its ability to compensate for distortion effects in all orientations throughout its usable tilt range. As we have mentioned, a compass must measure the local field vector generated by the host system at its current position within the system in order to accurately calibrate. Because the TCM3/5/5L's magnetometer is strapped-down, or fixed with respect to its host system, this local field vector does not change as the host system's attitude changes, allowing the TCM3/5/5L to accurately compensate in all pitch and roll orientations. Gimbaleed fluxgates, for instance, are unable to provide accurate calibration in non-level orientations because its magnetometers, being gimbaleed, change position with respect to the host system as attitude changes. This presents a different local distortion field than that measured during calibration.

### Key Points

- The minimum points the unit can use for a successful calibration is 12.
- The unit will need to be rotated through at least 180 degrees in the horizontal plane with minimum of at least 1 positive and 1 negative Pitch and Roll.
- Tilt as much as possible during the calibration. This allows the compass to take full advantage of the 3-axis magnetometer.
- You are trying to get an even sampling of the magnetic field over as many headings and tilts as possible, including upside down if possible.
- Pay attention to the coverage percentage. The lower the percentage the less accurate the compass.



## Calibration Theory

The exact calibration method will depend on the actual settings of the calibration parameters. An example of the various settings and their effect can be seen in the **TCM Studio – Evaluation Software** section.

The main object of the calibration is to allow the TCM3/5/5L to calibrate out any distortions to the magnetic field caused by the host system. To that end the TCM3/5/5L needs to be mounted within the host system and the entire application needs to be moved as a single unit during the calibration. Movement should include at least 180° of horizontal rotation, but to achieve the highest accuracy a full 360° of horizontal rotation with as many different tilt angles as possible during the rotation is required.

To achieve the highest accuracy throughout the TCM3/5/5L's entire tilt range, the unit will need to be tilted through the entire range. For example, if the unit is only tilted through 40° of pitch and roll, then the heading information from the TCM3/5/5L will only be accurate through 40° of pitch and roll. For maximum performance the TCM3/5/5L should be exposed to tilt angles covering a full 360°, meaning upside down.

## *Hard and Soft Iron Effects*

**Hard iron** distortions are caused by permanent magnets and magnetized steel or iron object within close proximity to the sensors. This type of distortion will remain constant and in a fixed location relative to the sensors for all heading orientations. Hard-iron distortions will add a constant magnitude field component along each axis of sensor output and can be easily compensated for using a simple saturation method.

**Soft-iron** distortions are the result of interactions between the Earth's magnetic field and any magnetically "soft" material within close proximity to the sensors. In technical terms, soft materials have a high permeability. The permeability of a given material is a measure of how well it serves as a path for magnetic lines of force, relative to air, which has an assigned permeability of one.


The TCM3/5/5L 3-axis digital compass features soft-iron and hard-iron correction.

## Pitch and Roll


The TCM3/5/5L uses accelerometers to measure the orientation of the compass with respect to gravity. Since the compass also measures the complete magnetic field, the TCM3/5/5L can correct for the tilt of the compass to provide an accurate heading.

The TCM3/5/5L utilizes Euler angles as the method for determining accurate orientation. This method is the same used in aircraft orientation where the outputs are Heading (Yaw), Pitch and Roll. When using Euler angles pitch and roll are defined as the angle rotated around an axis through the center of the fuselage; pitch is rotation around an axis through the center of the wings. These two rotations are independent of each other since the rotation axes rotate with the plane body.

For the TCM3/5/5L a *positive pitch* is when the *front edge of the board is rotated upward* and a *positive roll* is when the *right edge of the board is rotated downward*.



### TCM3/5 Standard Mounting



### TCM5L Standard Mounting

## *Declination Value*

Declination, also called magnetic variation, is the difference between true and magnetic north, relative to a point on the earth. It is measured in degrees east or west of true north. Correcting for declination is accomplished by storing the correct declination angle, and then changing the heading reference from magnetic north to true north. Declination angles vary throughout the world, and change very slowly over time. For the greatest possible accuracy, go to the National Geophysical Data Center web page below to get the declination angle based on your latitude and longitude: <http://www.ngdc.noaa.gov/cgi-bin/seg/gmag/fldsnt1.pl>

## *Other Limitations*


As discussed, the TCM3/5/5L models local disturbances as a static magnetic vector contribution to the earth's field. Any local fields, which are not static, will create errors. You cannot calibrate for anomalies that are not fixed with respect to the compass. For example, you may know that the TCM3/5/5L will be used in close proximity to other vehicles. You cannot calibrate for the effects of these other vehicles, as they will be moving with respect to the TCM3/5/5L. This is a limitation universal to all compasses. Consider, therefore, the TCM3/5/5L's position relative to any potential sources of field that will not be static: magnetic cargo or payloads that may be placed in close proximity, fans or other electrical equipment that may be turned on and off, and so on.

The TCM3/5/5L can calibrate for any environment that creates a magnetic field that does not exceed the dynamic range of its magnetometers.

# Binary Protocol – RS232 Interface

## Datagram Structure

Transport Layer for RS-232 communication:



**Note:**

1. ByteCount is the total number of bytes in the packet including the CRC-16
2. CRC-16 is calculated starting from the ByteCount to the last byte of the Packet Frame (see included C function at end of document).
3. ByteCount and CRC-16 are always transmitted in BIG ENDIAN.


## Parameter Formats

### Floating Point

The floating-point based parameters are in the IEEE standard format, ANSI/IEEE Std 754-1985.

#### 64-Bit (double precision floating point)

Shown below is the 64-bit float format in big endian, in little endian bytes are in reverse order in 4 byte groups (ie: big endian: ABCDEFGH little endian: DCBA HGFE).



The value (v) is determined as (if and only if  $0 < \text{Exponent} < 2047$ ):  $v = (-1)^S * 2^{(\text{Exponent}-1023)} * 1.\text{Mantissa}$

#### 32-Bit (single precision floating point)

Shown below is the 32-bit float format in big endian, in little endian all 4 bytes are in reverse order (LSB first).




The value (v) is determined as (if and only if  $0 < \text{Exponent} < 255$ ):  $v = (-1)^S * 2^{(\text{Exponent}-127)} * 1.\text{Mantissa}$


**Note: Please refer to ANSI/IEEE Std 754-1985 for more information. It is also recommended that you refer to the compiler you are using on how it implements floating-point formats.**

**Signed 32-bit Integer (SInt32)**

SInt32 based parameters are signed 32 bit numbers (2's compliment). Bit 31 represents the sign of the value (0=positive, 1=negative)




Big Endian




Little Endian

**Signed 16-bit Integer (SInt16)**

SInt16 based parameters are signed 16 bit numbers (2's compliment). Bit 15 represents the sign of the value (0=positive, 1=negative)




Big Endian



Little Endian


**Signed 8-bit Integer (SInt8)**

UInt8 based parameters are unsigned 8-bit numbers. Bit 7 represents the sign of the value (0=positive, 1=negative)




### **Unsigned 32-bit Integer (UInt32)**

UInt32 based parameters are unsigned 32 bit numbers.




Big Endian




Little Endian

### **Unsigned 16-bit Integer (UInt16)**

UInt16 based parameters are unsigned 16 bit numbers.




Big Endian



Little Endian


### **Unsigned 8-bit Integer (UInt8)**

UInt8 based parameters are unsigned 8-bit numbers.



### **Boolean**

Boolean is a 1-byte parameter that MUST have the value 0 (false) or 1 (true).



## Commands & Communication Frames

### Overview:

Frame ID	Command	Description
1	kGetModInfo	Queries the modules type and firmware revision number.
2	kModInfoResp	Response to kGetModInfo
3	kSetDataComponents	Sets the data components to be output.
4	kGetData	Queries the module for data
5	kDataResp	Response to kGetData
6	kSetConfig	Sets internal configurations in the module
7	kGetConfig	Queries the module for the current internal configuration value
8	kConfigResp	Response to kGetConfig
9	kSave	Commands the module to save internal and user calibration
10	kStartCal	Commands the module to start user calibration
11	kStopCal	Commands the module to stop user calibration
12	kSetParam	Sets the FIR filter settings for the magnetometer & accelerometer sensors.
13	kGetParam	Queries for the FIR filter settings for the magnetometer & accelerometer sensors.
14	kParamResp	Contains the FIR filter settings for the magnetometer & accelerometer sensors.
15	kPowerDown	Used to completely power-down the module
16	kSaveDone	Response to kSave
17	kUserCalSampCount	Sent from the module after taking a calibration sample point
18	kUserCalScore	Contains the calibration score
19	kSetConfigDone	Response to kSetConfig
20	kSetParamDone	Response to kSetParam
21	kStartIntervalMode	Commands the module to output data at a fixed interval
22	kStopIntervalMode	Commands the module to stop data output at a fixed interval
23	kPowerUp	Sent after wake up from power down mode
24	kSetAcqParams	Sets the sensor acquisition parameters
25	kGetAcqParams	Queries for the sensor acquisition parameters
26	kAcqParamsDone	Response to kSetAcqParams
27	kAcqParamsResp	Response to kGetAcqParams
28	kPowerDownDone	Response to kPowerDown
29	kFactoryUserCal	Clears user calibration coefficients
30	kFactorUserCalDone	Response to kFactoryUserCal
31	kTakeUserCalSample	Commands the unit to take a sample during user calibration

### kGetModInfo (frame ID 1)


This frame queries the module's type and firmware revision number. The frame has no payload. The complete packet for the kGetModInfo command would be:

0005	01	EFD4
------	----	------

with 0005 being the byte count  
01 kGetModInfo command  
EFD4 CRC-16 checksum


### kModInfoResp (frame ID 2)

This frame is the response to **kGetModInfo** frame. The payload contains the module type identifier followed by the firmware revision number.




### kSetDataComponents (frame ID 3)

This frame sets the data components in the module's data output. This is not a query for the module's data (see **kGetData**). The first byte of the payload indicates the number of data components followed by the data component IDs.



#### **Example:**

To query the heading and pitch, the payload should contain:



When querying for data (**kGetData** frame), the sequence of the data component output follows the sequence of the data component IDs as set in this frame.



## Component Identifiers

Component	DataComponentID	Format	Units	Range
kHeading	5	Float32	degrees	0.0° to 359.9°
kTemperature	7	Float32	° Celsius	-40° to 85°
kDistortion	8	Boolean	True or False	False (Default) = no distortion
kCalStatus	9	Boolean	True or False	False (Default) = not calibrated
kPCalibrated	21	Float32	mG	-1.0 to 1.0
kRCalibrated	22	Float32	mG	-1.0 to 1.0
kIZCalibrated	23	Float32	mG	-1.0 to 1.0
kPAngle	24	Float32	degrees	-90.0° to 90.0°
kRAngle	25	Float32	degrees	-180.0° to 180.0°
KXAligned	27	Float32	μT	
KYAligned	28	Float32	μT	
KZAligned	29	Float32	μT	

## Component Types for kSetDataComponents & kDataResp frames

### ***kHeading***

Compass heading output.

### ***kTemperature***

This is sampled from the internal temperature sensor of the module. Its value is in ° Celsius and has an accuracy of +/- 3° C.

### ***kDistortion***

Read only flag that indicates that at least one magnetometer axis reading is beyond +/- 80 μT.

### ***kCalStatus***

Read only flag that indicates user calibration status. False (Default) = Not calibrated.

### ***kPCalibrated, kRCalibrated & kIZCalibrated***

Factory calibrated Earth's acceleration vector (G) component output.

### ***kPAngle, kRAngle***

Pitch and Roll angle outputs. Pitch is equal to -90.0° to 90.0° and Roll is equal to -180.0° to 180.0°.

### ***kXAligned, kYAligned, kZAligned***

User calibration Earth's magnetic field (M) vector component output.

## kGetData (frame ID 4)


This frame queries the module for data. The frame has no payload. The complete packet for the kGetModInfo command would be:

00 05	04	BF71
-------	----	------

with 00 05 being the byte count  
 04 kGetData command  
 BF71 CRC-16 checksum

## kDataResp (frame ID 5)

The frame is the response to **kGetData** frame. The first byte of the payload indicates the number of data components then followed by the data component ID-value pairs. The sequence of the components Ids follows the sequence set in the **kSetDataComponents** frame.




### Example:

If the response contains the heading and pitch output, the payload would look like:

2	5	359.9	24	10.5
ID Count	Heading ID	Heading Output (Float32)	Pitch ID	Pitch Output (Float32)

## kSetConfig (frame ID 6)

This frame sets internal configurations in the module. The first byte of the payload is the configuration ID followed by a format specific value. These configurations can only be set one at time.



### Example:

To configure the declination, the payload would look like:

1	10.0
---	------

Declination ID      Declination  
Angle  
(Float32)

### Configuration Identifiers

Settings	Configuration ID	Format	Units/ Range	Default Values																
kDeclination	1	Float32	-180° to 180°	0°																
kTrueNorth	2	Boolean	True or False	False																
kBigEndian	6	Boolean	True or False	True																
kMountingRef	10	UInt8	1 = Standard 2 = X axis up 3 = Y axis up 4 = -90° heading offset 5 = -180° heading offset 6 = -270° heading offset 7 = Z down 8 = X + 90° 9 = X + 180° 10 = X + 270° 11 = Y + 90° 12 = Y + 180° 13 = Y + 270° 14 = Z down + 90° 15 = Z down + 180° 16 = Z down + 270°	1																
kUserCalStableCheck	11	Boolean	True or False	True																
kUserCalNumPoints	12	UInt32	12 – 50	50																
kUserCalAutoSampling	13	Boolean	True or False	True																
kBaudRate	14	UInt8	<table border="0"> <tr> <td>0 – 300</td> <td>8 – 9600</td> </tr> <tr> <td>1 – 600</td> <td>9 – 14400</td> </tr> <tr> <td>2 – 1200</td> <td>10 – 19200</td> </tr> <tr> <td>3 – 1800</td> <td>11 – 28800</td> </tr> <tr> <td>4 – 2400</td> <td>12 – 38400</td> </tr> <tr> <td>5 – 3600</td> <td>13 – 57600</td> </tr> <tr> <td>6 – 4800</td> <td>14 – 115200</td> </tr> <tr> <td>7 – 7200</td> <td>15 – 230400</td> </tr> </table>	0 – 300	8 – 9600	1 – 600	9 – 14400	2 – 1200	10 – 19200	3 – 1800	11 – 28800	4 – 2400	12 – 38400	5 – 3600	13 – 57600	6 – 4800	14 – 115200	7 – 7200	15 – 230400	12
0 – 300	8 – 9600																			
1 – 600	9 – 14400																			
2 – 1200	10 – 19200																			
3 – 1800	11 – 28800																			
4 – 2400	12 – 38400																			
5 – 3600	13 – 57600																			
6 – 4800	14 – 115200																			
7 – 7200	15 – 230400																			

#### ***kDeclination***

This sets the declination angle to determine True North heading. Positive declination is easterly declination and negative is westerly declination. This is not applied until TrueNorth is set to true.

#### ***kTrueNorth***

Flag to set compass heading output to true north heading by adding the declination angle to the magnetic north heading.

#### ***kBigEndian***

Flag to set the Endianness of packets

### ***kMountingRef***

This sets the reference orientation for the module.

- **Standard:** When selected the unit is to be mounted with the main board in a horizontal position (the Z axis magnetic sensor is vertical).
- **X Sensor Up:** When selected the unit is to be mounted with the main board in a vertical position (the X axis magnetic sensor is vertical).
- **Y Sensor Up:** When selected the unit is to be mounted with the main board in a vertical position (the Y axis magnetic sensor is vertical).
- **Standard 90 Degrees:** When selected the unit is to be mounted with the main board in a horizontal position but rotated so the arrow is pointed 90 degrees counterclockwise to the front of the host system.
- **Standard 180 Degrees:** When selected the unit is to be mounted with the main board in a horizontal position but rotated so the arrow is pointed 180 degrees counterclockwise to the front of the host system.
- **Standard 270 Degrees:** When selected the unit is to be mounted with the main board in a horizontal position but rotated so the arrow is pointed 270 degrees counterclockwise to the front of the host system.

### ***kUserCalStableCheck***

This flag is used during user calibration. If set to FALSE, the module will take a point if the magnetic field has changed more than 23  $\mu\text{T}$  in either axis. If set to TRUE the unit will take a point if the magnetic field has a stability of 30 $\mu\text{T}$  in each direction and the previous point changed more than 5 $\mu\text{T}$  and acceleration vector delta within 2 mg.

### ***kUserCalNumPoints***

The maximum number samples taken during user calibration.

### ***kUserCalAutoSampling***


This flag is used during user calibration. If set to TRUE, the module continuously takes calibration sample points until the set number of calibration samples. If set to FALSE, the module waits for kTakeUserCalSample frame to take a sample with the condition that a magnetic field vector component delta is greater than 5 micro Tesla from the last sample point.

### ***kBaudRate***

Baud rate index value. A power-down power-up cycle is required when changing the baud rate.


## **kGetConfig (frame ID 7)**

This frame queries the module for the current internal configuration value. The payload contains the configuration ID requested.



## kConfigResp (frame ID 8)

This frame is the response to **kGetConfig** frame. The payload contains the configuration ID and value.



### **Example:**

If a request to get the set declination angle, the payload would look like:

1	10.0
Declination ID	Declination Angle (Float32)

## kSave (frame ID 9)

This frame commands the module to save internal configurations and user calibration to non-volatile memory. Internal configurations and user calibration is restored on power up. The frame has no payload. This is the **ONLY** command that causes the module to save information into non-volatile memory.

## kStartCal (frame ID 10)


This frame commands the module to start user calibration with the current sensor acquisition parameters, internal configurations and FIR filter settings.

## kStopCal (frame ID 11)

This frame commands the module to stop calibration points sampling and calculate the calibration score and coefficients.

## kSetParam (frame ID 12)

This frame sets the FIR filter settings for the magnetometer and accelerometer sensors. The second byte of the payload indicates the x vector component of either the magnetometer or accelerometer. This is to differentiate whether to apply the filter settings to the magnetometer or accelerometer. The third byte in the payload indicates the number of FIR taps to use then followed by the filter taps. Each tap is a Float64. The maximum number of taps that can be set is 32 and the minimum is 0 (no filtering). (See Recommended FIR Filter Taps).



### Parameter Identifiers


Settings	Parameter ID	Format
KFIRConfig*	3	AxisID (UInt8) + Count (UInt8) + Value (Float64) + Value (Float64) + ...

### Recommended FIR Filter Tap Value

2Count	4 Tap Filter	8 Tap Filter	16 Tap Filter	32 Tap Filter
1	04.6708657655334e-2	01.9875512449729e-2	07.9724971069144e-3	01.4823725958818e-3
2	04.5329134234467e-1	06.4500864832660e-2	01.2710056429342e-2	02.0737124095482e-3
3	04.5329134234467e-1	01.6637325898141e-1	02.5971390034516e-2	03.2757326624196e-3
4	04.6708657655334e-2	02.4925036373620e-1	04.6451949792704e-2	05.3097803863757e-3
5		02.4925036373620e-1	07.1024151197772e-2	08.3414139286254e-3
6		01.6637325898141e-1	09.5354386848804e-2	01.2456836057785e-2
7		06.4500864832660e-2	01.1484431942626e-1	01.7646051430536e-2
8		01.9875512449729e-2	01.2567124916369e-1	02.3794805168613e-2
9			01.2567124916369e-1	03.0686505921968e-2
10			01.1484431942626e-1	03.8014333463472e-2
11			09.5354386848804e-2	04.5402682509802e-2
12			07.1024151197772e-2	05.2436112653103e-2
13			04.6451949792704e-2	05.8693165018301e-2
14			02.5971390034516e-2	06.3781858267530e-2
15			01.2710056429342e-2	06.7373451424187e-2
16			07.9724971069144e-3	06.9231186101853e-2
17				06.9231186101853e-2
18				06.7373451424187e-2
19				06.3781858267530e-2
20				05.8693165018301e-2
21				05.2436112653103e-2
22				04.5402682509802e-2
23				03.8014333463472e-2
24				03.0686505921968e-2
25				02.3794805168613e-2
26				01.7646051430536e-2
27				01.2456836057785e-2
28				08.3414139286254e-3
29				05.3097803863757e-3
30				03.2757326624196e-3
31				02.0737124095482e-3
32				01.4823725958818e-3


### kGetParam (frame ID 13)

This frame queries the FIR filter settings for the magnetometer and accelerometer sensors. The first byte of the payload is the kFIRConfig ID followed by the vector axis ID (byte).



### kParamResp (frame ID 14)

This frame contains the current FIR filter settings for either magnetometer or accelerometer sensors. The second byte of the payload is the vector axis ID, the third byte is the number of filter taps then followed by the filter taps. Each tap is a Float64.




### kPowerDown (frame ID 15)

This frame is used to completely power-down the module. The frame has no payload. The unit will power down all peripherals including the RS-232 driver but the driver chip has the feature to keep the Rx line enabled. Any character sent to the module causes it to exit power down mode. It is recommended to send the byte 0xFFh.


### kSaveDone (frame ID 16)

This frame is the response to **kSave** frame. The payload contains a UInt16 error code, 0000h indicates no error, 0001h indicates error when attempting to save data into non-volatile memory.




## kUserCalSampCount (frame ID 17)

This frame is sent from the module after taking a calibration sample point. The payload contains the sample count with the range of 1 to 50



## kUserCalScore (frame ID 18)

This frame's payload contains the calibration score, which is a series of Float32 values: stdDevErr, xCoverage, yCoverage, zCoverage, magBearth, magHI.



**StdDevErr** : The compass samples magnetic field standard deviation error.

**XCoverage** : Percentage of how much of the X magnetometer axis was covered by the sampling.

**YCoverage** : Percentage of how much of the Y magnetometer axis was covered by the sampling.

**ZCoverage** : Percentage of how much of the Z magnetometer axis was covered by the sampling.

**MagBearth** : The calculated Earth's magnetic field magnitude from the calibration samples.

**MagHI** : Reserved value; always 0.

## kSetConfigDone (frame ID 19)

This frame is the response to **kSetConfig** frame. The frame has no payload.

## kSetParamDone (frame ID 20)

This frame is the response to **kSetParam** frame. The frame has no payload.

## kStartIntervalMode (frame ID 21)

The frame commands the module to output data (push mode) at a fixed time interval (See **kSetAcqParams**). The frame has no payload.



## kStopIntervalMode (frame ID 22)


This frame commands the module to stop data output at a fixed time interval. The frame has no payload.

## kPowerUp (frame ID 23)

This frame is sent from the module after wake up from power down mode. The frame has no payload. Since the module was previously powered down which drives the RS-232 driver TX line low (break signal), it is recommended to disregard the first byte.

## kSetAcqParams (frame ID 24)

This frame sets the sensor acquisition parameters in the unit. The payload should contain the following:



### ***PollingMode***

Flag to set push/pull data output mode. Default is TRUE (pull mode).

### ***FlushFilter***

Flag to set FIR filter flushing every sample. Default is FALSE (no flushing).

### ***SensorAcqTime***

The internal time interval between sensor acquisitions. Default is 0.0 seconds, this means that the module will reacquire immediately right after the last acquisition.

### ***IntervalRespTime***

The time interval the module output data in push mode. Default is 0.0 seconds, this means that the module will push data out immediately after an acquisition cycle.

## kGetAcqParams (frame ID 25)

This frame queries the unit for the acquisition parameters. The frame has no payload.

## kAcqParamsDone (frame ID 26)

This frame is the response to **kSetAcqParams** frame. The frame has no payload.

### **kAcqParamsResp (frame ID 27)**

This frame is the response to **kGetAcqParams** frame. The payload should contain the same payload as the **kSetAcqParams** frame.

### **kPowerDownDone (frame ID 28)**

This frame is the response to **kPowerDown** frame. This indicates that the unit successfully received the **kPowerDone** frame and is in the process of powering down. The frame has no payload.

### **kFactoryUserCal (frame ID 29)**

This frame clears the user calibration coefficients. The frame has no payload.

### **kFactoryUserCalDone (frame ID 30)**

This frame is the response to **kFactoryUserCal** frame. The frame has no payload.

### **kTakeUserCalSample (frame ID 31)**

This frame commands the unit to take a sample during user calibration. The frame has no payload.

# TCM3/5/5L Code Examples

## Binary TCM High Performance Protocol C Header File & CRC-16 Function

```
// type declarations
typedef struct
{
    UInt8 pollingMode, flushFilter;
    Float32 sensorAcqTime, intervalRespTime;
} __attribute__((packed)) AcqParams;

typedef struct
{
    Float32 stdDevErr;
    Float32 xCoverage;
    Float32 yCoverage;
    Float32 zCoverage;
    Float32 magBearth;
    Float32 reservel;
} __attribute__((packed)) CalScore;

enum
{
    // Frame IDs (Commands)
    kGetModInfo = 1, // 1
    kModInfoResp, // 2
    kSetDataComponents, // 3
    kGetData, // 4
    kDataResp, // 5
    kSetConfig, // 6
    kGetConfig, // 7
    kConfigResp, // 8
    kSave, // 9
    kStartCal, // 10
    kStopCal, // 11
    kSetParam, // 12
    kGetParam, // 13
    kParamResp, // 14
    kPowerDown, // 15
    kSaveDone, // 16
    kUserCalSampCount, // 17
    kUserCalScore, // 18
    kSetConfigDone, // 19
    kSetParamDone, // 20
    kStartIntervalMode, // 21
    kStopIntervalMode, // 22
    kPowerUp, // 23
    kSetAcqParams, // 24
    kGetAcqParams, // 25
    kAcqParamsDone, // 26
    kAcqParamsResp, // 27
    kPowerDoneDown, // 28
    kFactoryUserCal, // 29
    kFactoryUserCalDone, // 30
    kTakeUserCalSample, // 31

    // Param IDs
    kFIRConfig = 1, // 3-AxisID(UInt8)+Count(UInt8)+Value(Float64)+...

    // Data Component IDs
    kHeading = 1, // 5 - type Float32
    kTemperature = 7, // 7 - type Float32
    kDistortion = 8, // 8 - type boolean
    kPCalibrated = 21, // 21 - type Float32
}
```

```

kRCalibrated,          // 22 - type Float32
kIZCalibrated,        // 23 - type Float32
kPAngle,              // 24 - type Float32
kRAngle,              // 25 - type Float32
kXAligned = 27,       // 27 - type Float32
kYAligned,            // 28 - type Float32
kZAligned,            // 29 - type Float32

// Configuration Parameter IDs
kDeclination = 1,     // 1 - type Float32
kTrueNorth,          // 2 - type UInt8
kMountingRef = 10,   // 10 - type UInt8
kUserCalStableCheck, // 11 - type boolean
kUserCalNumPoints,   // 12 - type UInt8
kUserCalAutoSampling, // 13 - type boolean
kBaudRate,           // 14 - UInt8

// Mounting Reference IDs
kMountedStandard = 1, // 1
kMountedXUp,         // 2
kMountedYUp,         // 3
kMountedStdPlus90,   // 4
kMountedStdPlus180,  // 5
kMountedStdPlus270,  // 6

// Result IDs
kErrNone = 0,        // 0
kErrSave,           // 1
};

// function to calculate CRC-16
UInt16 CRC(void * data, UInt32 len)
{
    UInt8 * dataPtr = (UInt8 *)data;
    UInt32 index = 0;
    // Update the CRC for transmitted and received data using
    // the CCITT 16bit algorithm (X^16 + X^12 + X^5 + 1).
    UInt16 crc = 0;
    while(len--)
    {
        crc = (unsigned char)(crc >> 8) | (crc << 8);
        crc ^= dataPtr[index++];
        crc ^= (unsigned char)(crc & 0xff) >> 4;
        crc ^= (crc << 8) << 4;
        crc ^= ((crc & 0xff) << 4) << 1;
    }
    return crc;
}

```

## Binary TCM Protocol C++ Communication Examples

The following 4 example files, CommProtocol.h, CommProtocol.cp, TCM5.h and TCM5.cp would be used together for proper communication with a TCM3, TCM5 or TCM5L module.

### CommProtocol.h File:

```
#pragma once

#include "SystemSerPort.h"
#include "Processes.h"

//
// This file contains objects used to handle the serial communication with the unit.
//

//
// CommHandler is a base class that provides a callback for incoming messages.
//
class CommHandler
{
public:
    // Call back to be implemented in derived class.
    virtual void HandleComm(UInt8 frameType, void * dataPtr = NULL, UInt16 dataLen =
0) {}
};

//
// CommProtocol handles the actual serial communication with the unit.
// Process is a base class that provides CommProtocol with cooperative parallel
processing. The Control method will be
// called by a process manager on a continuous basis.
//
class CommProtocol : public Process
{
public:
    enum
    {
        // Frame IDs (Commands)
        kGetModInfo = 1, // 1
        kModInfoResp, // 2
        kSetDataComponents, // 3
        kGetData, // 4
        kDataResp, // 5

        // Data Component IDs
        kHeading = 5, // 5 - type Float32
        kTemperature = 7, // 7 - type Float32
        kPCalibrated = 21, // 21 - type Float32
        kRCalibrated, // 22 - type Float32
        kIZCalibrated, // 23 - type Float32
        kPAngle, // 24 - type Float32
        kRAngle, // 25 - type Float32
    };

    enum
    {
        kBufferSize = 512, // maximum size of our input buffer
        kPacketMinSize = 5 // minimum size of a serial packet
    };

    // SerPort is a serial communication object abstracting the hardware
implementation
    CommProtocol(CommHandler * handler = NULL, SerPort * serPort = NULL);

    void Init(UInt32 baud = 38400);

    void SendData(UInt8 frame, void * dataPtr = NULL, UInt32 len = 0);
    void SetBaud(UInt32 baud);

protected:
    CommHandler * mHandler;
    SerPort * mSerialPort;

    UInt8 mOutData[kBufferSize], mInData[kBufferSize];
};
```

```

        UInt16 mExpectedLen;
        UInt32 mOutLen, mOldInLen, mTime, mStep;

        UInt16 CRC(void * data, UInt32 len);
        void Control();
};

```

## CommProtocol.cp File:

```

#include "CommProtocol.h"

// import an object that will provide a 10mSec tick count through a function called
// Ticks()
#include "TickGenerator.h"

//
// SerPort is an object that controls the physical serial interface. It handles sending
// out
// the characters, and buffers the characters read in until we are ready for them.
//
CommProtocol::CommProtocol(CommHandler * handler, SerPort * serPort)
: Process("CommProtocol")
{
    mHandler = handler; // store the object that will parse the data
    when it is fully received
    mSerialPort = serPort;
    Init();
}

//
// Initialize the serial port and variables that will control this process
//
void CommProtocol::Init(UInt32 baud)
{
    SetBaud(baud);
    mOldInLen = 0; // no data previously received

    mStep = 1; // goto the first step of our process
}

//
// Put together the frame to send to the unit
//
void CommProtocol::SendData(UInt8 frameType, void * dataPtr, UInt32 len)
{
    UInt8 * data = (UInt8 *)dataPtr; // the data to send
    UInt32 index = 0; // our location in the frame we are putting
    together
    UInt16 crc; // the CRC to add to the end of the packet
    UInt16 count; // the total length the packet will be

    count = (UInt16)len + kPacketMinSize;

    // exit without sending if there is too much data to fit inside our packet
    if(len > kBufferSize - kPacketMinSize) return;

    // Store the total len of the packet including the len bytes (2), the frame ID (1),
    // the data (len), and the crc (2). If no data is sent, the min len is 5
    mOutData[index++] = count >> 8;
    mOutData[index++] = count & 0xFF;

    // store the frame ID
    mOutData[index++] = frameType;

    // copy the data to be sent
    while(len--) mOutData[index++] = *data++;

    // compute and add the crc
    crc = CRC(mOutData, index);
    mOutData[index++] = crc >> 8;
    mOutData[index++] = crc & 0xFF;

    // Write block will copy and send the data out the serial port
    mSerialPort->WriteBlock(mOutData, index);
}

```

```

//
// Call the functions in serial port necessary to change the baud rate
//
void CommProtocol::SetBaud(UInt32 baud)
{
    mSerialPort->SetBaudRate(baud);
    mSerialPort->InClear();           // clear any data that was already waiting in
the buffer
}

//
// Update the CRC for transmitted and received data using the CCITT 16bit algorithm (X^16
+ X^12 + X^5 + 1).
//
UInt16 CommProtocol::CRC(void * data, UInt32 len)
{
    UInt8 * dataPtr = (UInt8 *)data;
    UInt32 index = 0;

    UInt16 crc = 0;
    while(len--)
    {
        crc = (unsigned char)(crc >> 8) | (crc << 8);
        crc ^= dataPtr[index++];
        crc ^= (unsigned char)(crc & 0xff) >> 4;
        crc ^= (crc << 8) << 4;
        crc ^= ((crc & 0xff) << 4) << 1;
    }
    return crc;
}

//
// This is called each time this process gets a turn to execute.
//
void CommProtocol::Control()
{
    // InLen returns the number of bytes in the input buffer of the serial object that
are available
    // for us to read.
    UInt32 inLen = mSerialPort->InLen();

    switch(mStep)
    {
        case 1:
        {
            // wait for length bytes to be received by the serial object
            if(inLen >= 2)
            {
                // Read block will return the number of requested (or available) bytes
that are in the
                // serial objects input buffer.
                // read the byte count
                mSerialPort->ReadBlock(mInData, 2);

                // byte count is ALWAYS transmitted in big endian, copy byte count to
mExpectedLen to
                // native endianness
                mExpectedLen = (mInData[0] << 8) | mInData[1];

                // Ticks is a timer function. 1 tick = 10msec.
                // wait up to 1/2s for the complete frame (mExpectedLen) to be
received
                mTime = Ticks() + 50 ;
                mStep++ ;           // goto the next step in the process
            }
            break ;
        }

        case 2:
        {
            // wait for msg complete or timeout
            if(inLen >= mExpectedLen - 2)
            {
                UInt16 crc, crcReceived;           // calculated and received crcs.

                // Read block will return the number of requested (or available) bytes
that are in the
                // serial objects input buffer.
                mSerialPort->ReadBlock(&mInData[2], mExpectedLen - 2);
                // in CRC verification, don't include the CRC in the recalculation (-
2)
                crc = CRC(mInData, mExpectedLen - 2);
            }
        }
    }
}

```

```

        // CRC is also ALWAYS transmitted in big endian
        crcReceived = (mInData[mExpectedLen - 2] << 8) | mInData[mExpectedLen
- 1] ;

        if(crc == crcReceived)
        {
            // the crc is correct, so pass the frame up for processing.
            if(mHandler)      mHandler->HandleComm(mInData[2],      &mInData[3],
mExpectedLen - kPacketMinSize);
        }
        else
        {
            // crc's don't match so clear everything that is currently in the
input buffer since
            // the data is not reliable.
            mSerialPort->InClear();
        }

        // go back to looking for the length bytes.
        mStep = 1 ;
    }
    else
    {
        // Ticks is a timer function.  1 tick = 10msec.
        if(Ticks() > mTime)
        {
            // Corrupted message. We did not get the length we were expecting
within 1/2sec of receiving
            // the length bytes. Clear everything in the input buffer since
the data is unreliable
            mSerialPort->InClear();
            mStep = 1 ;                // Look for the next length bytes
        }
    }
    break ;
}
default:
    break ;
}
}
}

```



## TCM5.h File (For TCM3, TCM5 and TCM5L Modules):

```
#pragma once

#include "Processes.h"
#include "CommProtocol.h"

//
// This file contains the object providing communication to the TCM3/5/5L. It will set
// up the unit and parse packets received
// Process is a base class that provides TCM3/5/5L with cooperative parallel processing.
// The Control method will be
// called by a process manager on a continuous basis.
//
class TCM3/5/5L : public Process, public CommHandler
{
public:
    TCM3/5/5L(SerPort * serPort);
    ~TCM3/5/5L();

protected:
    CommProtocol * mComm;

    UInt32 mStep, mTime, mResponseTime;

    void HandleComm(UInt8 frameType, void * dataPtr = NULL, UInt16 dataLen = 0);
    void SendComm(UInt8 frameType, void * dataPtr = NULL, UInt16 dataLen = 0);

    void Control();
};
```

## TCM5.cp File (For TCM3, TCM5 & TCM5L Modules):

```
#include "TCM3/5/5L.h"
#include "TickGenerator.h"

const UInt8 kDataCount = 4;          // We will be requesting 4 componets (Heading, pitch,
roll, temperature)
//
// This object polls the TCM3/5/5L unit once a second for heading, pitch, roll and
temperature.
//

TCM3/5/5L::TCM3/5/5L(SerPort * serPort)
: Process("TCM3/5/5L")
{
    // Let the CommProtocol know this object will handle any serial data returned by the
unit
    mComm = new CommProtocol(this, serPort);

    mTime = 0;
    mStep = 1;
}

TCM3/5/5L::~TCM3/5/5L()
{
}

//
// Called by the CommProtocol object when a frame is completely received
//
void TCM3/5/5L::HandleComm(UInt8 frameType, void * dataPtr, UInt16 dataLen)
{
    UInt8 * data = (UInt8 *)dataPtr;

    switch(frameType)
    {
        case CommProtocol::kDataResp:
        {
            // Parse the data response
            UInt8 count = data[0];          // The number of data elements returned
            UInt32 pntr = 1;                // Used to retrieve the returned elements

            // The data elements we requested
            Float32 heading, pitch, roll, temperature;

            if(count != kDataCount)
            {
                // Message is a function that displays a C formatted string (similar
to printf)
                Message("Received %u data elements instead of the %u requested\r\n",
(UInt16)count,
                (UInt16)kDataCount);
                return;
            }

            // loop through and collect the elements
            while(count)
            {
                // The elements are received as {type (ie. kHeading), data}
                switch(data[pntr++])// read the type and go to the first byte of the
data
                {
                    // Only handling the 4 elements we are looking for
                    case CommProtocol::kHeading:
                    {
                        // Move(source, destination, size (bytes)). Move copies the specified number of
// bytes from the source pointer to the destination pointer.
                        // Store the heading.
                        Move(&(data[pntr]), &heading, sizeof(heading));

                        // increase the pointer to point to the next data element
                        pntr += sizeof(heading);
                        break;
                    }

                    case CommProtocol::kPAngle:
                    {
                        // Move(source, destination, size (bytes)). Move copies the
specified number of
                        // bytes from the source pointer to the destination pointer.
                    }
                }
            }
        }
    }
}
```

```

        // Store the pitch.
        Move(&(data[pntr]), &pitch, sizeof(pitch));

        // increase the pointer to point to the next data element
type
        pntr += sizeof(pitch);
        break;
    }

    case CommProtocol::kRAngle:
    {
        // Move(source, destination, size (bytes)). Move copies the
specified number of
        // bytes from the source pointer to the destination pointer.
        // Store the roll.
        Move(&(data[pntr]), &roll, sizeof(roll));

        // increase the pointer to point to the next data element
type
        pntr += sizeof(roll);
        break;
    }

    case CommProtocol::kTemperature:
    {
        // Move(source, destination, size (bytes)). Move copies the
specified number of
        // bytes from the source pointer to the destination pointer.
        // Store the heading.
        Move(&(data[pntr]), &temperature, sizeof(temperature));

        // increase the pointer to point to the next data element
type
        pntr += sizeof(temperature);
        break;
    }

    default:
    {
        // Message is a function that displays a formatted string
(similar to printf)
        Message("Unknown type: %02X\r\n", data[pntr - 1]);
        // unknown data type, so size is unknown, so skip everything
        return;
        break;
    }
    }

    count--; // One less element to read in
}

// Message is a function that displays a formatted string (similar to
printf)
Message("Heading: %f, Pitch: %f, Roll: %f, Temperature: %f\r\n", heading,
pitch, roll,
    temperature);
mStep--; // send next data request
break;
}

default:
{
    // Message is a function that displays a formatted string (similar to
printf)
    Message("Unknown frame %02X received\r\n", (UInt16)frameType);
    break;
}
}

//
// Have the CommProtocol build and send the frame to the unit.
//
void TCM3/5/5L::SendComm(UInt8 frameType, void * dataPtr, UInt16 dataLen)
{
    if(mComm) mComm->SendData(frameType, dataPtr, dataLen);
    // Ticks is a timer function. 1 tick = 10msec.
    mResponseTime = Ticks() + 300; // Expect a response within 3 seconds
}

//
// This is called each time this process gets a turn to execute.
//
void TCM3/5/5L::Control()
{

```

```

switch(mStep)
{
    case 1:
    {
        UInt8 pkt[kDataCount + 1];    // the compents we are requesting, preceded
by the number of...                // ...components being requested

        pkt[0] = kDataCount;
        pkt[1] = CommProtocol::kHeading;
        pkt[2] = CommProtocol::kPAngle;
        pkt[3] = CommProtocol::kRAngle;
        pkt[4] = CommProtocol::kTemperature;

        SendComm(CommProtocol::kSetDataComponents, pkt, kDataCount + 1);

        // Ticks is a timer function.  1 tick = 10msec.
        mTime = Ticks() + 100;        // Taking a sample in 1s.
        mStep++;                      // go to next step of process
        break;
    }

    case 2:
    {
        // Ticks is a timer function.  1 tick = 10msec.
        if(Ticks() > mTime)
        {
            // tell the unit to take a sample
            SendComm(CommProtocol::kGetData);
            mTime = Ticks() + 100;    // take a sample every second
            mStep++;
        }
        break;
    }

    case 3:
    {
        // Ticks is a timer function.  1 tick = 10msec.
        if(Ticks() > mResponseTime)
        {
            Message("No response from the unit.  Check connection and try
again\r\n");
            mStep = 0;
        }
        break;
    }

    default:
        break;
}
}

```

# Performance Specifications

Parameter	TCM3	TCM5	TCM5L	Units
<b>Heading Specifications</b>				
Accuracy with <70° of tilt	0.5°	0.3°	0.3°	Deg RMS
Accuracy with >70° of tilt	0.8°	0.5°	0.5°	
Resolution	0.1°	0.1°	0.1°	
Repeatability [1]	0.05°	0.05°	0.05°	
Max Dip Angle	85°	85°	85°	Deg
<b>Magnetometer Specifications</b>				
Calibrated Field Measurement Range	± 80	± 80	± 80	µT
Magnetic Resolution	± 0.05	± .05	± .05	
Magnetic Repeatability	± 0.1	± 0.1	± 0.1	
<b>Tilt Specification</b>				
Pitch Accuracy	0.2°	0.2°	0.2°	Deg RMS
Roll Accuracy	0.2° for Pitch < 65°	0.2° for Pitch < 65°	0.2° for Pitch < 65°	
	0.5° for Pitch < 80°	0.5° for Pitch < 80°	0.5° for Pitch < 80°	
	1.0° for Pitch < 86°	1.0° for Pitch < 86°	1.0° for Pitch < 86°	
Tilt Range	± 80°	± 90° pitch ± 180° roll	± 90° pitch ± 180° roll	Deg
Tilt Resolution	< 0.01°	< 0.01°	< 0.01°	Deg RMS
Tilt Repeatability [1]	0.05°	0.05°	0.05°	
<b>Calibration</b>				
Hard Iron Calibration	Yes	Yes	Yes	
Soft Iron Calibration	Yes	Yes	Yes	
<b>Mechanical Specifications</b>				
Dimensions (L x W x H)	3.5 x 4.3 x 1.3	3.5 x 4.3 x 1.3	3.3 x 3.1 x 1.3*	cm
Weight	12	12	12*	grams
Mounting Options	Screw mounts/standoffs; horizontal		Screw mounts/standoffs; horizontal or vertical	
Connector for RS-232	9-pin	9-pin	4-pin	
<b>I/O Specifications</b>				
Latency from Power-On	< 210*	< 210*	< 210*	mSec
Latency from Sleep Mode	< 1	< 1	< 1	
Maximum Sample Rate	20	20	20	samples/sec
RS-232 Communication Rate	300 to 230400	300 to 230400	300 to 230400	baud
Output Formats	Binary High Performance Protocol			
<b>Power Specifications</b>				
Supply Voltage	3.6 to 5 V (unregulated)	3.6 to 5 V (unregulated)	3.6 to 5 V (unregulated)	VDC
Current Draw	<b>Max.</b> 22	22	22	mA
(Continuous Output)	<b>Typ.</b> < 20	< 20	< 20	
Idle Mode [2]	14 - 18	14 - 18	14 - 18	
Sleep Mode	0.6	0.6	0.6	
<b>Environmental Specifications</b>				
Operating Temperature	-30° to 85°	-40° to 85°	-40° to 85°	C
Storage Temperature	-40° to 85°	-40° to 125°	-40° to 125°	
Shock	Up to 2500 G's, per MIL-STD-810F			
Vibrations	Qualified to MIL-STD-810F			
Humidity	Non-condensing/Qualified to MIL-STD-810F			


[1] Repeatability is based on statistical data at ±3 sigma limit about the mean

\* Other options may be available.


# Mechanicals

## TCM3/5

The default orientation for the TCM3/5/5L is for the silk-screened arrow to point in the “forward” direction. That puts the edge opposite of the Molex connector as the front edge of the board.



## 18 in. Cable Assembly




- ② Molex p/n 51146-0900
- ③ Molex p/n 50641-8141

PIN	Wire Color	Description
1	Black	Power Ground
2	Gray	NC
3	Green	RS232 Ground
4	Orange	NC
5	Violet	NC
6	Brown	NC
7	Yellow	TxD
8	Blue	RxD
9	Red	5 VDC

### Molex Connector Pin Description

## TCM5L Board

The default orientation for the TCM5L is for the silk-screened arrow to point in the “forward” direction.



### TCM5L Pin Descriptions

PIN	Description
1	Power Ground
2	5 VDC Supply
3	TxD (RS232)
4	RxD (RS232)

**No cable available for TCM5L**