



TCM2.5 and TCM2.6 Command List

Commands Unchanged from TCM2-20 or TCM2-50

ax	Warm reboot
c?	Compass Update
i?	Inclinometer Update
m?	Magnetometer Update
s?	Single Update Output Word
t?	Temperature Update
cc	Clear Calibration Data
mpcal=	Multipoint Calibration
sleep	Sleep Mode (improved sleep mode over TCM2)
wake	Wake Mode (requires separate program and connection of RTS pin)
damping=	Enable Filter for damping of output
ec=	Enable Compass Data for Output Word
em=	Enable Magnetometer Data for Output Word
ep=	Enable Pitch Data for Output Word
er=	Enable Roll Data for Output Word
et=	Enable Temperature Data for Output Word
ma=	Select Magnetometer Output Option
mag_dec=	Set Declination Angle
sn=	Select Magnetic or True North
uc=	Set Compass Units
ui=	Set Inclinometer Units
ut=	Set Temperature Units



TCM2.5 and TCM2.6 Command List

Commands Changed from TCM2-20/TCM2-50

- b=** Set Baud rate
- Changes value upon ENTER
 - 1 = 300
 - 2 = 1200
 - 3 = 2400
 - 4 = 4800
 - 5 = 9600 (default)
 - 6 = 19200
 - 7 = 38400
 - 8 = 11500 (new value)
- timeconst=** Set the value for filtering (damping) of outputs. Values will be rounded up to one of 4 discrete values:
- 1 – 4 will be set to 4
 - 5 – 8 will be set to 8
 - 9 – 16 will be set to 16
 - 17-32 will be set to 32
- sdo=** The new TCM units use an ASIC instead of discrete components. As a result the raw data is no longer available in the same way.
- 'sdo = t' Standard TCM output string
 - 'sdo = n' NMEA 0183 output string
 - 'sdo = r' Obsolete
- factory** Factor Settings (some of the defaults have changed)
- | | |
|-------------|-------------|
| b =5 | halt=d |
| cc | ma=u |
| damping=d | mag_dec=0.0 |
| ec=e | mpcal=d |
| ed=e | sdo=t |
| em=d | sn=m |
| ep=e | uc=d |
| er=e | ui=d |
| et=d | ut=c |
| timeconst=8 | sp=8 |
- sp=** Set sampling period divisor implementation has changed
- sp = Hz
 - clock command / sp = Hz is no longer needed



TCM2.5 and TCM2.6 Command List

Commands Changed from TCM2-20/TCM2-50 (cont.)

- halt= Enable Single Character Halt has changed slightly. TCM2.5 and TCM2.6 implementation
- h=
- Stops the unit
 - Performs a save
 - Reports action complete
- Instead of TCM2-20 and TCM2-50
- h=
- Stops the unit
 - Reports action complete (though not necessarily complete)
 - Performs a save
- go Go mode has changed
- When cycling power in go mode, the first 1-2 readings will be erroneous
- lc? Query Last Calibration Score
- TCM2.5 and TCM2.6: Cal score is accessible only after multipoint calibration is disabled (mpcal=d)
 - TCM2-20 and TCM2-50: Cal score is accessible during and after multipoint calibration



TCM2.5 and TCM2.6 Command List

Commands Removed

To keep the software compatible with existing systems, when any of the commands below are sent, the unit will respond with the ":" as if it had accepted the command. Querying the command will result in an error code, since the command is obsolete and not being used.

autocal	Autocalibration (not used)
%skip=	Skip measurements (new filtering is superior, no longer needed)
cclip=	Set Clip Value
clock=	Set Clock rate (no longer needed)
ed=	Enable Magnetic Distortion Alarm (caused confusion; new method is superior)
fast=	Enable Fast Sampling (no longer needed)
sao=	Select Analog Output Option (no analog output available)
save	Unit automatically saves any changed settings (no longer needed)
serialp=	Lower Power Serial Consumption (specific to older chip)
cal3	Three Point Calibration (not used) [Responds with E010]